

# Daily Inspection Requirements

**Drivers:** Inspect, check and **correct** or **notify** mechanics **daily**:

1. Loose or missing parts
- 2. All fluid leaks and levels**
3. All lights, tail lights, horn, fan belt, tires, lug nuts
4. Grease all zerk fittings
- 5. Inspect/lubricate front/rear drive chains, sprockets**
6. Cab's Air ride, air bags/adjust to eliminate bottoming out
7. Clean garbage from engine area
8. Cab safety cables '08 – up models
9. Lubricate all chains/cables per operator's manual
10. Inspect/test lift arm – 5 second (up/down) cycle is proper
- 11. Operating RPM 2200-2500**
12. Max RPM 2600 (Intermittent ONLY)
- 13. Drain water contamination from the fuel filter daily-before operation**
- 14. Clean between radiator(s) to get proper air flow and engine cooling**